

# IOTA Watch QuickStart



Turn the watch on by clicking the crown button.

The watch has three front face modes. You can switch between modes by swiping left and right across the watch face with your finger.

## Clock Mode

Simply displays the time, date and a discreet IOTA logo.  
Enter the main menu by double tapping the watch face anywhere.

## Chart Mode

Displays live price and chart.  
Swipe up and down on this screen to change the chart range: day, week, month, quarter, year.  
Enter the main menu by single tapping the top time bar.

## Node Mode

Displays live node info status, audio alert if node goes unhealthy.  
Enter the main menu by single tapping the top time bar.

## Main Menu

From here you can access the wallet, apps and settings.  
To exit back to your watch face, single tap the top title bar.

## Things To Do

1. Charge your watch using any regular USB outlet.
2. Go into the main menu/settings/language and select your language.
3. Go into the main menu/settings/wifi and select your network and enter your password and enable the wifi checkbox. After successful wifi connection your watch will chirp and the wifi status indicators (in chart and node modes) will show connected.
4. Explore all of the watch's menus and functions and have fun!

